VANTRUE®
Dual Dash Cam

VANTRUE®
Dual Dash Cam
User Manual

OnDash N2

CE FC UL
WEEE IC EAC

说明书印刷要求：
1.纸张：单页尺寸：90*130(mm)；
整页尺寸：190*130（mm）
2.装订方式:骑马

Contents

01 Safety Notice 1
02 Product Overview 3
1.1 Product Features 3
1.2 Package Contents 3
1.3 Button Function Configuration 3
1.4 Device Installation 4
1.5 Screen Configuration 5
1.6 LED Indicator 6
1.7 Connect & Remove the microSD Card 6
1.8 Initial Setup 6
1.9 Formatting the microSD Card 6
1.10 Firmware Update 6
03 Basic Operations 7
2.1 Turning on/off the Device 7
2.2 Video Recording 7
2.3 Parking Mode 7
2.4 Emergency Button 7
2.5 Snapshot 7
2.6 Playback 7
2.7 Delete Files 7
2.8 Setup Menu 7
04 Q & A 10
Warranty & Support 17
Deutsche bedienungsanleitung 18-27
中文说明书 28-40
日本語説明書 50-65

Thank you for purchasing Vantrue OnDash N2 Dash Cam!
Please read this manual carefully before using the product and keep it for future reference. Please strictly follow the safety, operation and installation instructions to ensure proper use and optimal performance. Failure to follow these instructions may result in damage to the product, fire, electric shock, or other hazards.

Cautions for Safety

- Do not disassemble, repair, or modify the product yourself.
- Do not expose the device to high temperature, direct sunlight, or extreme temperatures. Overheat will be a serious hazard for fire hazard or explosion.
- Do not use the product in environments with flammable gas, such as gasoline stations.
- Do not forcibly bend or pull the cable, or place heavy objects on it. Damaged cables may cause fire or electric shock.
- Do not touch the power cable with wet hands. Doing so may cause electrical shock.
- Use only the recommended accessories and power adapter. Using incompatible or low-quality accessories may damage the device or cause fire.
- Do not place the product in unstable or vibrate places. Sudden impact may damage the internal components.
- Do not block the lens or sensors during driving.
- Do not expose lens to strong light sources (sunlight, or concentrated lamps or flashlights) for long periods, as this may damage the image sensor.
- Do not use the product in the hot and dusty place. This product has a rear heat dissipation vent. Avoid blocking the vent with objects or placing the device in a narrow space with insufficient airflow. Poor ventilation may cause overheating and affect performance.
- Do not use the product in the rain or near water. This product is not waterproof. Exposure to moisture may cause short circuits, corrosion, or electrical hazards.
- Do not use the product while driving. Operating the device while driving may distract the driver and cause accidents. Please adjust the settings before driving.
- Do not place the product in the airbag deployment area. Airbags deploy rapidly and may damage the device or cause injuries.
- Do not use the product in a moving or shaking vehicle. Vibration may affect the stability of the recording and shorten the lifespan of the device.
- If smoke, or an unusual smell is noticed from the power cord, stop it immediately and unplug the power cord. Continue use may cause fire or electrical hazards. Keep the removed the power cord clean.

01 Safety Notice

Cautions for Safety

- Use the correct input voltage.
- Do not short circuit the power cable. Short circuit can cause sparks, fire, or electrical shock.
- Do not touch the power cable during thunderstorms. Lightning may cause electrical shock.
- Do not use damaged cables or loose connections. Damaged cables may cause fire or electrical shock.
- Do not pull the power cable when unplugging. Pull the plug, not the cable, to avoid damage.
- Do not place the device in high-temperature areas. Prolonged exposure to high temperatures may damage the internal components.
- Do not use the product in environments with chemicals or corrosive gas. Chemicals may damage the device and cause malfunctions.
- Do not use the product in high-humidity environments. Moisture may cause short circuits or electrical hazards.
- Do not use the product in dusty environments. Dust may affect the lens and internal components, causing malfunctions.
- Do not use the product in high-altitude environments. Low pressure may affect the performance of the battery and other components.
- Do not use the product in areas with strong electromagnetic interference. Interference may affect the normal operation of the device.
- Do not use the product in areas with high static electricity. Static electricity may damage the circuit components.
- Do not use the product in areas with high vibration. Vibration may affect the stability of the recording and shorten the lifespan of the device.
- Do not use the product in areas with high noise. Noise may affect the performance of the microphone and the quality of the recorded audio.
- Do not use the product in areas with high electromagnetic radiation. Electromagnetic radiation may affect the normal operation of the device.
- Do not use the product in areas with high radiation. Radiation may affect the performance of the sensor and the quality of the recorded video.
- Do not use the product in areas with high pressure. High pressure may affect the performance of the battery and other components.
- Do not use the product in areas with high humidity. Humidity may affect the performance of the battery and other components.
- Do not use the product in areas with high temperature. High temperature may affect the performance of the battery and other components.
- Do not use the product in areas with low temperature. Low temperature may affect the performance of the battery and other components.
- Do not use the product in areas with high altitude. High altitude may affect the performance of the battery and other components